



Figure 2. Storm water control measures and flow directions at the Lone Star Northwest East Marginal Way facility.

➡ Direction of storm water flow